



Directions for use: SHAKE WELL!

1. Remove lid and dip foam applicator into solution.
2. Apply by painting on cold glass with long strokes, covering the entire build area.
3. Place glass onto heatbed and preheat.

Airwolf 3D™
www.airwolf3d.com

IMPORTANT!!!

One dip of the foam applicator is enough to coat an entire 12" x 12" piece of glass. Be conservative with the solution, as too much can lead to difficulty in removing parts and can even damage the glass. If your parts are difficult to remove after printing, you can run water over the glass and parts to help debond. After the parts are removed from the glass, take a wet cloth and gently wipe down the glass print surface. This will prep the bed for the next print. You can print multiple times with this method without re-applying the solution. Airwolf 3D assumes no liability for misuse of Wolfbite.



Directions for use: SHAKE WELL!

1. Remove lid and dip foam applicator into solution.
2. Apply by painting on cold glass with long strokes, covering the entire build area.
3. Place glass onto heatbed and preheat.

Airwolf 3D™
www.airwolf3d.com

IMPORTANT!!!

One dip of the foam applicator is enough to coat an entire 12" x 12" piece of glass. Be conservative with the solution, as too much can lead to difficulty in removing parts and can even damage the glass. If your parts are difficult to remove after printing, you can run water over the glass and parts to help debond. After the parts are removed from the glass, take a wet cloth and gently wipe down the glass print surface. This will prep the bed for the next print. You can print multiple times with this method without re-applying the solution. Airwolf 3D assumes no liability for misuse of Wolfbite.